




## CONNECTING ONT TO ROUTER



Please make sure the ethernet cable that came in the free to use router box is connected to the free to use Yutiliti Router as seen below One end of the ethernet cable is to be connected to the router into the WAN/INTERNET (Yellow Port)



Please make sure the ethernet cable that came in the free to use router box is connected to the ONT (White fibre box the team will install in the property). This end to be connected into the LAN 1 port on the ONT, (Furthest Yellow Port from where the power cable plugs into this device)



Please make sure the power cable supplied is connected and plugged into a stable multi-plug connected to your electrical socket.



If connected correctly you will see POWER light green and stable PON light green and stable. LAN1 green and flickering



## CONNECTING UPS TO ROUTER and ONT

### CONNECTING UPS DEVICE

Step 1: Make sure the UPS is on (Battery Symbol lights on).

Step 1a: Make sure Status and 12V Lights are on and green.

Step 2: Connect Splitter Cable single side to UPS.

Step 3: Connect Splitter Cable Double Side 1 to the ONT.


Step 4: Connect Splitter Cable Double Side 2 to the extension cable.

Step 5: Connect Extension Cable to Router.

Step 6: Make Sure ONT is powered on.

Step 7: Make Sure the Router is on.

Step 8: Make Sure selector is set to 12V.



## WIFI DETAILS AND INFORMATION

Yutiliti free to use routers are pre- configured devices

USERNAME: Defaulted to the surname (lastname) on the account.

PASSWORD: Defaulted to the cell phone number on the account.

The WIFI details will always be defaulted to the above unless specified with unique WIFI details on order form. WIFI Password required to be 8 characters in length. If the default username and password do not work, please check your order form to confirm the unique details you have chosen.

Yutiliti Free to use routers remain the property of Yutiliti. Yutiliti does not provide back end access to these devices for support reasons. Any changes you would like to be made to be mailed to [support@yutiliti.co.za](mailto:support@yutiliti.co.za). If you would like to use your own equipment, an email request from the account holder is required for Yutiliti to provide you with your PPPoE details required to authenticate on our network.